Wireless Internet Keyboard and Optical Mouse

User's Manual

Model KB985W

FCC STATEMENT
KB985W

This device complies with part 15 of FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction guide, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult a service representative for help.

Properly shielded and grounded cables and connectors must be used in order to comply with FCC emission limits. Micro Innovations is not responsible for any radio or television interference caused by using other than recommended cables and connectors or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

Responsible party:
Micro Innovations
400 Clearview Ave.
Edison, NJ 08837
Telephone: 732-346-9333

FC
Tested To Comply With FCC Standards
FOR HOME OR OFFICE USE

Table of Contents

Welcome…… Page 4

Installation Procedures…… Page 5

Programmable Hot Key Settings…… Page 6

Hot Key Definitions…… Page 7

Troubleshooting…… Page 8

Maintenance and Technical Support…… Page 9

Some experts believe that the use of any keyboard may cause serious injury to hands, arms, neck, or back. If you feel any pain, numbness, or weakness in these areas seek help from a qualified health professional immediately.

TO REDUCE THE RISKS OF SUCH INJURIES FOLLOW THESE PRECAUTIONS

- Take frequent short breaks
- Vary your tasks throughout the day
- Keep your shoulders relaxed with your elbows at your side
- Position you keyboard and mouse so you do not have to reach for them
- Adjust your chair so your wrists are straight
- Avoid resting your wrists on sharp desk edges

Welcome

Congratulations on the purchase of your new Wireless Internet Keyboard and Optical Mouse.

The Wireless Internet Keyboard and Optical Mouse is compatible with IBM® or compatible PCs with an available USB port. It is supported by 2000, XP and Vista™.

Features and Benefits

Launch your favorite Windows® applications, digital music and Internet with a touch of one button.

An 800 dpi optical sensor scans the desktop surface at up to 3000fps (frames per second) for accuracy and control.

Insta-Link™ technology connects your wireless keyboard and mouse with the RF receiver instantly without synching.

Package Contents

- Wireless Keyboard and Optical Mouse
- RF Receiver (USB)
- Installation CD with User's Manual
- 4 Duracell AA Batteries
- Quick Installation Guide
- Warranty Information

Installation Procedures

1



Open the battery compartment located underneath the keyboard and install 2 AA batteries.

2



Open the battery compartment located underneath the mouse and install 2 AA batteries. Make sure power switch is in the "on" position.

3



Turn on your PC.

4



Insert the USB connector into an available USB port. Your PC will make the proper settings to operate your keyboard and mouse.

5



Install the software CD.

Your new keyboard and mouse is now ready for use. To save battery power, use the on / off switch located underneath the mouse.

If your keyboard and mouse does not work automatically, please follow the synchronization steps below.
Note you may also have to perform this procedure when changing the batteries.

Step 1 – Press the "connect" button underneath the keyboard
Step 2 – Press the "connect" button underneath the mouse

Programmable Hot Key Settings

To enable the programmable hot key functions, click Start⇒ Programs⇒ Micro Innovations⇒ Wireless Keyboard

The following icon will appear in the lower right-hand corner of your system tray. To launch the keyboard settings interface (Fig.1), click the keyboard icon. Highlight the name of the key and select “Setting...” button. The following window will appear:



The programmable hot keys are designed to perform specific operations that are labeled as “Predefine Function.” You can disable their functionality by selecting “Turn Key Off”. Note: You can return to all predefined functions by selecting the “Default Function” button. To assign a program or website, choose “Run Program/Open Web” and click “Next”. Type in the name of the function and choose program or website address. Click “Ok” to finish.

Hot key Definitions



1. Press this button to go back a webpage
2. Press this button to launch default home page
3. Press this button to go forward a page
4. Press this button to open a search window
5. Press this button to launch your default e-mail
6. Press this button to refresh the page
7. Press this button to launch My Favorites
8. Press this button to open My Computer
9. Press this button to launch the Calculator
10. Press this button to turn the mute on/off
11. Press this button to decrease the volume
12. Press this button to increase the volume
13. Press this button to play/pause the media file
14. Press this button to go back a track
15. Press this button to queue forward track
16. Press this button to stop the media file

Troubleshooting

Problem	Resolution
Keyboard hot keys do not work Keyboard is typing wrong characters	Try re-installing the software CD. Make sure that any previous keyboard drivers / software has been removed prior to using this device. *Please refer to the documentation that came with your previous keyboard or contact the manufacturer for this information.* Try moving the keyboard and mouse closer to the RF receiver.
Keyboard is not responding	You might have plugged in the keyboard while the computer was off. Turn on your computer and reconnect your keyboard into an available USB port.
Windows® Multimedia Player is not launching	You may need to update your Windows® Multimedia Player (WMP). **Note it is not recommended to use other media players with this device. Such programs may cause unexpected problems.*

Maintenance

- Maintaining your product will ensure longer life and will minimize the chance of causing damage to your keyboard and/or computer.
- Keep all beverages away from the keyboard and avoid any spills.
- Keep the user's manual for future reference.
- Keep the software CD in a safe place for future installations.
- There are no user serviceable parts. Only Micro Innovations may service or repair this product.

For technical assistance visit www.microinv.com or call toll free: 1-877-550-5534.
Technical Support hours of operation: Monday - Friday 8:30am to 7:00pm E.S.T.